

Section 3

Driveline / Axle**CONTENTS**

Precautions	3-1	Final Gear Assembly Removal and Installation	3A-3
Precautions	3-1	Final Gear Disassembly and Assembly	3A-4
Precautions for Driveline/Axle	3-1	Final Drive Gear Bearing Inspection	3A-8
Drive Chain / Drive Train / Drive Shaft...	3A-1	Specifications	3A-9
Diagnostic Information and Procedures	3A-1	Tightening Torque Specifications	3A-9
Drive Chain and Sprocket Symptom		Special Tools and Equipment	3A-9
Diagnosis	3A-1	Recommended Service Material	3A-9
Repair Instructions	3A-2	Special Tool	3A-9
Final Gear Components	3A-2		

Precautions

Precautions

Precautions for Driveline/Axle

Refer to "General Precautions in Section 00 (Page00-1)".

B705H23000001